



Lenovo Yoga 3 11 Lower Case Replacement

Replace the lower case in your Lenovo Yoga 3 11.

Written By: Geoff Wacker



INTRODUCTION

Use this guide to replace the lower case in your Lenovo Yoga 3 11.

TOOLS:

- [T5 Torx Screwdriver](#) (1)
-

Step 1 — Lower Case



- Remove the eleven 6 mm T5 Torx screws securing the lower case.
- Gently lift the lower case up and away from the device.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 03:00:58 AM.